

# Sun Blade™ 100 Motherboard Update and Sun PGX64 Patch Procedures

For Sun Blade 100 Systems with the Solaris™ 8 10/00, 1/01, or 4/01 Operating Environments

Sun Microsystems, Inc. 4150 Network Circle Santa Clara, CA 95054 U.S.A. 650-960-1300

Part No. 816-7660-10 July 2002, Revision A Copyright 2002 Sun Microsystems, Inc., 4150 Network Circle, Santa Clara, California 95054, U.S.A. All rights reserved.

Sun Microsystems, Inc. has intellectual property rights relating to technology embodied in the product that is described in this document. In particular, and without limitation, these intellectual property rights may include one or more of the U.S. patents listed at http://www.sun.com/patents and one or more additional patents or pending patent applications in the U.S. and in other countries.

This document and the product to which it pertains are distributed under licenses restricting their use, copying, distribution, and decompilation. No part of the product or of this document may be reproduced in any form by any means without prior written authorization of Sun and its licensors, if any.

Third-party software, including font technology, is copyrighted and licensed from Sun suppliers.

Parts of the product may be derived from Berkeley BSD systems, licensed from the University of California. UNIX is a registered trademark in the U.S. and in other countries, exclusively licensed through X/Open Company, Ltd.

Sun, Sun Microsystems, the Sun logo, Sun Blade, AnswerBook2, docs.sun.com, and Solaris are trademarks or registered trademarks of Sun Microsystems, Inc. in the U.S. and in other countries.

All SPARC trademarks are used under license and are trademarks or registered trademarks of SPARC International, Inc. in the U.S. and in other countries. Products bearing SPARC trademarks are based upon an architecture developed by Sun Microsystems, Inc.

The OPEN LOOK and  $Sun^{TM}$  Graphical User Interface was developed by Sun Microsystems, Inc. for its users and licensees. Sun acknowledges the pioneering efforts of Xerox in researching and developing the concept of visual or graphical user interfaces for the computer industry. Sun holds a non-exclusive license from Xerox to the Xerox Graphical User Interface, which license also covers Sun's licensees who implement OPEN LOOK GUIs and otherwise comply with Sun's written license agreements.

Use, duplication, or disclosure by the U.S. Government is subject to restrictions set forth in the Sun Microsystems, Inc. license agreements and as provided in DFARS 227.7202-1(a) and 227.7202-3(a) (1995), DFARS 252.227-7013(c)(1)(ii) (Oct. 1998), FAR 12.212(a) (1995), FAR 52.227-19, or FAR 52.227-14 (ALT III), as applicable.

DOCUMENTATION IS PROVIDED "AS IS" AND ALL EXPRESS OR IMPLIED CONDITIONS, REPRESENTATIONS AND WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT, ARE DISCLAIMED, EXCEPT TO THE EXTENT THAT SUCH DISCLAIMERS ARE HELD TO BE LEGALLY INVALID.

Copyright 2002 Sun Microsystems, Inc., 4150 Network Circle, Santa Clara, California 95054, Etats-Unis. Tous droits réservés.

Sun Microsystems, Inc. a les droits de propriété intellectuels relatants à la technologie incorporée dans le produit qui est décrit dans ce document. En particulier, et sans la limitation, ces droits de propriété intellectuels peuvent inclure un ou plus des brevets américains énumérés à http://www.sun.com/patents et un ou les brevets plus supplémentaires ou les applications de brevet en attente dans les Etats-Unis et dans les autres pays.

Ce produit ou document est protégé par un copyright et distribué avec des licences qui en restreignent l'utilisation, la copie, la distribution, et la décompilation. Aucune partie de ce produit ou document ne peut être reproduite sous aucune forme, parquelque moyen que ce soit, sans l'autorisation préalable et écrite de Sun et de ses bailleurs de licence, s'il y ena.

Le logiciel détenu par des tiers, et qui comprend la technologie relative aux polices de caractères, est protégé par un copyright et licencié par des fournisseurs de Sun.

Des parties de ce produit pourront être dérivées des systèmes Berkeley BSD licenciés par l'Université de Californie. UNIX est une marque déposée aux Etats-Unis et dans d'autres pays et licenciée exclusivement par X/Open Company, Ltd.

Sun, Sun Microsystems, le logo Sun, Sun Blade, AnswerBook2, docs.sun.com, et Solaris sont des marques de fabrique ou des marques déposées de Sun Microsystems, Inc. aux Etats-Unis et dans d'autres pays.

Toutes les marques SPARC sont utilisées sous licence et sont des marques de fabrique ou des marques déposées de SPARC International, Inc. aux Etats-Unis et dans d'autres pays. Les produits protant les marques SPARC sont basés sur une architecture développée par Sun Microsystems, Inc.

L'interface d'utilisation graphique OPEN LOOK et Sun™ a été développée par Sun Microsystems, Inc. pour ses utilisateurs et licenciés. Sun reconnaît les efforts de pionniers de Xerox pour la recherche et le développment du concept des interfaces d'utilisation visuelle ou graphique pour l'industrie de l'informatique. Sun détient une license non exclusive do Xerox sur l'interface d'utilisation graphique Xerox, cette licence couvrant également les licenciées de Sun qui mettent en place l'interface d'utilisation graphique OPEN LOOK et qui en outre se conforment aux licences écrites de Sun.

LA DOCUMENTATION EST FOURNIE "EN L'ÉTAT" ET TOUTES AUTRES CONDITIONS, DECLARATIONS ET GARANTIES EXPRESSES OU TACITES SONT FORMELLEMENT EXCLUES, DANS LA MESURE AUTORISEE PAR LA LOI APPLICABLE, Y COMPRIS NOTAMMENT TOUTE GARANTIE IMPLICITE RELATIVE A LA QUALITE MARCHANDE, A L'APTITUDE A UNE UTILISATION PARTICULIERE OU A L'ABSENCE DE CONTREFAÇON.





# Sun Blade 100 Motherboard Update and Sun PGX64 Patch Procedures

# Procedure Overview and Patch Description

Installing a new motherboard into the Sun Blade<sup>TM</sup> 100 may cause the system monitor to go blank if the system is using certain Solaris<sup>TM</sup> releases. A patch resolves the problem. To order the patch kit, contact your Sun service representative.

This procedure is only required for Sun Blade 100 workstations with motherboard part number 375-3106 *and* one of these Solaris releases:

- Solaris 8 10/00
- Solaris 8 1/01
- Solaris 8 4/01

These procedures should only be performed by experienced system administrators or authorized Sun service representatives.

**Note** – There are two main procedures in this document. Each procedure is distinctly different depending on the system configuration. Be sure to follow the correct procedure for your system.

■ Patch Procedure 1 is necessary if your Sun Blade 100 workstation *is currently operating* with Solaris 8 10/00, 1/01, or 4/01 and requires a new motherboard, part number 375-3106.

■ Patch Procedure 2 is necessary if you have a workstation that already has a motherboard, part number 375-3106, with Solaris 8 7/01 or later installed, and you want to install an earlier version of Solaris 8 (10/00, 1/01, or 4/01).

# Identifying the Motherboard

All motherboards that require the patch will have part number 375-3106 on a label or silk-screened onto the board. See FIGURE 1.




FIGURE 1 The Motherboard Part Number Label or Silkscreen is Near the Edge Connector

# Removing and Replacing the Motherboard, CPU, and DIMMs

# **Required Tools and Documentation**

- A #2 Phillips screwdriver
- Sun Blade 100 Service Manual, 806-3416

Follow the procedures in the *Sun Blade 100 Service Manual*, Chapter 8, "Removing and Replacing the Motherboard and Related Components."

The service manual was provided on a CD-ROM that shipped with your workstation. The service manual is online at:

http://www.sun.com/documentation

Click the following links:

Additional Hardware Documentation -> Desktop & Workstation -> Sun Blade Workstations. Then click on the link for the Sun Blade 100.

# Motherboard Replacement Procedure

- 1. Follow the procedures in the *Sun Blade 100 Service Manual* to remove the CPU and DIMMs from the original motherboard.
- 2. Install the CPU and DIMMs onto the new motherboard.
- 3. Install the new motherboard into the Sun Blade 100 workstation.
- 4. Connect all the cables to the system.

# Patch Procedure 1: Installing the Sun PGX64 Patch on Sun Blade 100 Workstations with Solaris 8 10/00, 1/01, or 4/01

# **Required Tools**

■ Sun PGX64 CD

## Before You Begin

Only use this procedure if your Sun Blade 100 workstation is currently operating with Solaris 8 10/00, 1/01, or 4/01.

# Adding the PGX64 Patch

- 1. Power on the system.
- 2. As soon as you see the Sun Blade 100 system banner, press Stop-A.

```
Sun Blade 100 (UltraSPARC-IIe), Keyboard Present Copyright 1998-2002 Sun Microsystems, Inc. All rights reserved. OpenBoot 4.6, 128 MB memory installed, Serial #516xxxxxx. Ethernet address 0:x:xx:xx:xx:xx, Host ID: 8x1x3xxx.
```

The system stops loading the Solaris operating environment and displays the ok prompt.

3. Boot the system in single user mode by typing:

```
ok boot -s
```

The system boots and asks for your root password.

```
Resetting...
...
INIT: SINGLE USER MODE
Type control-d to proceed with normal startup
(or give root password for system maintenance)
```

4. Type the root password and press the Enter key.

The system displays the # prompt indicating that you are superuser.

- 5. Insert the PGX64 CD into the CD-ROM drive.
- 6. At the # prompt, type:

```
# mkdir /cdrom
```

7. Type:

```
# cd /
```

8. To mount the CD-ROM, type:

```
# mount -F hsfs /dev/dsk/c0t1d0s0 /cdrom
```

9. To access the directory on the CD-ROM which contains the patches, type:

```
# cd /cdrom/Solaris_8/Patches
```

10. Type 1s to determine the latest patch revision contained on the CD-ROM:

```
# 1s
108606-09
```

# 11. Type the patchadd command using the exact patch number in the /Patches directory:

# patchadd 108606-09

The system shows the packages being added and returns you to the command prompt.

#### 12. Power off the system.

The patch procedure is complete.

# Patch Procedure 2: Installing Earlier Solaris 8 Operating Environments and the Sun PGX64 Patch on Sun Blade 100 Workstations with Solaris 8 7/01 or Later

Use this procedure if you have a workstation that has a motherboard part number 375-3106 with Solaris 87/01 (or later) installed and you want to install Solaris 810/00, 1/01, or 4/01.

# **Required Tools**

- Solaris 8 10/00, 1/01, or 4/01 media kit
- Sun PGX64 CD

## **Recommended TTY Connection Procedure**

If possible, you should use a TTY connection to install the Solaris 8 operating environment and the PGX64 patch.

If you don't use the TTY procedure, you must complete an immediate system shutdown after installing Solaris 8 10/00, 1/01, or 4/01. Therefore, you may have to run fsck to clean the file system. The immediate shutdown is necessary because the PGX 64 patch is added after installing the Solaris 8 operating environment and the system monitor is blank until the PGX64 patch is installed.

If you use the TTY connection to install the Solaris 8 operating environment and the PGX64 patch, you can complete an orderly shutdown procedure and avoid the blank monitor problem and any file system repairs.

1. Power on the Sun Blade 100 workstation.

**Note** – If you will *not* use a TTY connection, begin your procedure with "Installing the Solaris 8 Operating Environment" on page 8.

2. At the ok prompt, type printenv to check the OpenBoot PROM parameters for the input and output devices:

```
ok printenv
```

3. Set the input-device to TTYA:

```
ok setenv input-device TTYA
```

4. Set the output-device to TTYA:

```
ok setenv output-device TTYA
```

5. Reset the OpenBoot PROM parameters:

```
ok reset-all resetting...
```

The TTY procedures are complete for the Sun Blade 100 system. Now set the remote console to communicate with the Sun Blade 100 system.

- 6. Connect the remote console device to the TTYA serial port.
- 7. Using the remote console, access the ok prompt and boot the Sun Blade 100 system in single user mode:

```
ok boot -s
```

Both systems are now ready for the Solaris 8 installation and the PGX64 patch installation.

# Installing the Solaris 8 Operating Environment

1. Install the Solaris 8 operating environment by following the directions provided in your Solaris media kit.

**Note** – Following the Solaris installation, the workstation monitor is blank. *If you are not using a TTY connection*, an immediate shutdown sequence is required before you can add the PGX64 patch. If you *are* using a TTY connection, an orderly shutdown is possible.

2. If you are using a TTY connection, halt the Sun Blade 100 system by typing sync and halt at the remote console:

```
# sync
# halt
```

Skip Step 3 and proceed with PGX64 patch installation.

- 3. If you are *not* using a TTY connection:
  - a. Press and hold the power button for four seconds to power off the Sun Blade 100 system.

Wait at least five seconds before powering on the system.

b. Power on the Sun Blade 100 system again by pressing the power button.

**Note** – You may need to run the fsck command to clean the file system after the power off and power on sequence.

# Adding the Sun PGX64 Patch

1. If you have not already powered on the Sun Blade 100 workstation, power on the workstation now.

### 2. As soon as you see the Sun Blade 100 system banner, press Stop + A.

```
Sun Blade 100 (UltraSPARC-IIe), Keyboard Present Copyright 1998-2002 Sun Microsystems, Inc. All rights reserved. OpenBoot 4.6, 128 MB memory installed, Serial #516xxxxxx. Ethernet address 0:x:xx:xx:xx. Host ID: 8x1x3xxx.
```

The system stops loading the Solaris operating environment and stops at the ok prompt.

### 3. Boot the Sun Blade 100 system in single user mode by typing:

```
ok boot -s
```

The system boots and asks for your root password.

```
Resetting...
...
INIT: SINGLE USER MODE
Type control-d to proceed with normal startup
(or give root password for system maintenance)
```

#### 4. Enter the root password and press the Enter key.

The system displays the # prompt indicating that you are superuser.

- 5. Insert the PGX64 CD into the CD-ROM drive.
- 6. At the # prompt, type:

```
# mkdir /cdrom
```

7. Type:

```
# cd /
```

8. To mount the CD-ROM, type:

```
# mount -F hsfs /dev/dsk/c0t1d0s0 /cdrom
```

9. To access the directory on the CD-ROM which contains the patches, type:

```
# cd /cdrom/Solaris_8/Patches
```

10. Type 1s to determine the latest patch revision contained on the CD-ROM:

```
# 1s 108606-09
```

11. Type the patchadd command:

```
# patchadd 108606-09
```

The system shows the packages being added and returns you to the command prompt.

12. If you are using a TTY connection, redirect the system to the OK prompt by typing:

```
# sync
# halt
```

If you are using a TTY connection, you should reset the Sun Blade 100 OpenBoot PROM input-device and output-device parameters to keyboard and screen.

13. Set the Sun Blade 100 input-device to keyboard:

```
ok setenv input-device keyboard
```

14. Set the Sun Blade 100 output-device to screen:

```
ok setenv output-device screen
```

15. Reset the Sun Blade 100 OpenBoot PROM parameters:

```
ok reset-all resetting...
```

The Sun Blade 100 workstation reboots.